

RH front door, LH side similar

14A584		B 1
C41		A 2
C42		A 2
C43		A 2
C488		C 4
C148		E 3
C149		E 3
C486		C 4
C487		C 4
C489		C 5
C738		A 3
C741		B 5
C782		E 1
C783		E 1
C794		D 4
C795		D 4
C807		B 4
C808		B 4
C937		E 2
C938		E 2
K50	One–touch window relay	A 3
M67	Door lock motor, driver side	E 3
M68	Door lock motor, passenger side	E 3
M75	Mirror motor, driver side	B 4
M76	Mirror motor, passenger side	B 4
M122	Window regulator motor, driver side front	E 2
M123	Window regulator motor, passenger side front	E 1
N70	Power mirror adjust switch	B 5
N137	Door lock/unlock switch, driver	D 4
N138	Door lock/unlock switch, passenger	D 4
N297	Window operating switch, passenger side front	C 5
N300	Window operating switch, driver side front (multiple)	C 5
Y18	Speaker, right front	E 2
Y28	Speaker, left front	E 2