Ignition switch (11572)

Schematic



Terminals



Component testing procedure

Circuit to test	Connect self–powered test light or ohm-meter to terminals	Move key to these positions	A good switch will indicate
Starter relay circuit	B4 and ST	Accessory, Lock Off, Run, Start	Closed circuit In Start, only
Ignition coil assembly	B5 and I1	Accessory, Lock Off, Run, Start	Closed circuit In Start, and Run, only
Accessory Power	B5 and A1	Accessory, Lock Off, Run, Start	Closed circuit In Accessory, only
Accessory Power	B5 and A1	Accessory, Lock Off, Run, Start	Closed circuit In Accessory, only
	B5 and A1	Accessory, Lock Off, Run, Start	Closed circuit In Accessory, only
	B5 and A1	Accessory, Lock Off, Run, Start	Closed circuit In Accessory, only
Accessory Power	B5 and A1	Accessory, Lock Off, Run, Start	Closed circuit In Accessory, only