C16 (GN)

14401



F10051

P91
Central Junction
Box (CJB)

Pin	Circuit	Circuit Function
1	15-AJ1 (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected)
2	29S-LF3 (OG/YE) +	Voltage supplied at all times (overload protected), switched
	29S-LF11 (OG/WH)	Voltage supplied at all times (overload protected), switched
	29S-LF7 (OG/BU) +	Voltage supplied at all times (overload protected), switched
	29S-LF11 (OG/WH)	Voltage supplied at all times (overload protected), switched
	15-FA13 (GN/RD)	Voltage, ignition switch in Start or Run (not overload protected)
	29S-LF3 (OG/YE)	Voltage supplied at all times (overload protected), switched
3	15-JA10 (GN/OG)	Voltage, ignition switch in Start or Run (not overload protected)
	29S-LF7 (OG/BU) +	Voltage supplied at all times (overload protected), switched
	29S-LF11 (OG/WH)	Voltage supplied at all times (overload protected), switched
4	29-HA6 (OG/YE)	Voltage supplied at all times (overload protected)
	29-HA6 (OG/YE) +	Voltage supplied at all times (overload protected)
	29-HA29 (OG/BK)	Voltage supplied at all times (overload protected)
5	15-AJ10 (GN/OG)	Voltage, ignition switch in Start or Run (not overload protected)
6	29S-LF1 (OG/YE)	Voltage supplied at all times (overload protected), switched
	15-JA10 (GN/OG)	Voltage, ignition switch in Start or Run (not overload protected)
7	15-FA13 (GN/RD) +	Voltage, ignition switch in Start or Run (not overload protected)
	15-FA38 (GN/RD)	Voltage, ignition switch in Start or Run (not overload protected)
	29S-LF16 (OG/GN) +	Voltage supplied at all times (overload protected), switched
	29S-LF20 (OG)	Voltage supplied at all times (overload protected), switched
8	29S-LF4 (OG/BU) +	Voltage supplied at all times (overload protected), switched
	29S-LF20 (OG)	Voltage supplied at all times (overload protected), switched
	29S-LF16 (OG/GN) +	Voltage supplied at all times (overload protected), switched
	29S-LF20 (OG)	Voltage supplied at all times (overload protected), switched
	29S-LF1 (OG/YE)	Voltage supplied at all times (overload protected), switched
9	15-LE14 (GN/RD) +	Voltage, ignition switch in Start or Run (not overload protected)
	15-LE29 (GN/BK)	Voltage, ignition switch in Start or Run (not overload protected)
10	15S-HB19 (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected), switched
	15-DA1 (GN/YE) +	Voltage, ignition switch in Start or Run (not overload protected)
	15-DA2 (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected)