CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C217	90-4
C224	90-5



Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.