C220a

14401

A30
Instrument cluster



F20017

Pin	Circuit	Circuit function
1	57 (BK)	Ground
2	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
3	904 (LG/RD)	Generator/Battery indicator, control
4	939 (VT)	traction assist, indicator, Lamp
5	419 (DG/LG)	Air suspension module (3C142), to, Instrumentation and Warning System
6	–	not used
7	2 (WH/LB)	Turn lamps, feed, right front
8	–	not used
9	–	not used
10	729 (RD/WH)	Voltage supplied at all times (overload protected)
11	1003 (GY/YE)	Voltage in Run (overload protected)
12	932 (GY/WH)	High beam lamp, feed
13	608 (BK/YE)	Air bag indicator, control
14	–	not used
15	–	not used
16	603 (DG)	Anti–lock brake indicator
17	162 (LG/RD)	Parking brake switch (15A851)
18	531 (DG/YE)	Brake fluid level switch (2L414), signal
19	512 (TN/LG)	Brake indicator, control
20	31 (WH/RD)	Engine oil pressure indicator, control

C220b

14401

A30
Instrument cluster



F22009

Pin	Circuit	Circuit function
1	914 (TN/OG)	SCP Bus +
2	915 (PK/LB)	SCP Bus –
3	29 (YE/WH)	Fuel pump/fuel gauge sender
4	3 (LG/WH)	Turn lamps, feed, left front
5	433 (DG/OG)	Door ajar indicator, Generic Electronic Module (GEM) (14B205)
6	–	not used
7	82 (PK/YE)	Low washer fluid indicator
8	–	not used
9	–	not used
10	450 (DG/LG)	Safety belt indicator, feed
11	–	not used
12	–	not used
13	–	not used
14	1216 (GY/OG)	RX, signal
15	1215 (WH/LG)	TX, signal
16	–	not used
17	676 (PK/OG)	logic ground
18	–	not used
19	–	not used
20	–	not used
21	–	not used
22	19 (LB/RD)	Instrument illumination