C304

14A504

B118
Side air bag sensor,
right (14B345)



F02069

Pin	Circuit	Circuit function
1	1264 (BN)	Air bag – passenger side impact – crash sensor to module – return
2	1263 (WH)	Air bag – driver side impact – crash sensor to module – feed

C305

14A504

B119
Side air bag sensor,
left (14B345)



F02069

Pin	Circuit	Circuit function
1	1262 (BN/LG)	Air bag – driver side impact – crash sensor to module – return
2	1261 (WH/LG)	Air bag – driver side impact – crash sensor to module – feed

C311

14K155



F02211

14A504



F02042

C312 (BK)

14A504



F04058

14B084



F04059

C313

14K155



F02211

14A504



F02042