14A488 - S29

Splice Location: **F7** - Near Side Impact Sensor, Passenger 2 T/O (C3212)

645 to Central Junction Box (CJB)
1003 to Low tire pressure module
645 to Central Security Module (CSM)
1003 to 14C719 Driver memory seat module

14A488 - S30

Splice Location: **B7** - Rear, RH Side Near Antenna T/O (C4082)

378 to 14398 Battery Junction Box (BJB)
378 to 14401 Multi-function switch
378 to Splice 13A409-S4

14A488 - S31

Splice Location: **B7** - Rear, RH Side Near Antenna gain module T/O (C4082)

693 to Central Security Module (CSM)
693 to Telematics Control Unit (TCU) module
693 to Splice 14C719-S2
693 to 14C719 Climate contr st mod, pass side
693 to Splice 14401-S19
693 to 14B079 Four-wheel drive control module

14A488 - S32

Splice Location: **B8** - Near RH Side D-Pillar

1043 to 14398 Battery Junction Box (BJB)
1043 to Auxiliary Junction Box (AJB)
1043 to Auxiliary Junction Box (AJB)

14A488 - S33

Splice Location: **A4** - Near RH Passenger Door Grommet

53 to 14334 Interior map lamps asy, front
53 to Auxiliary Junction Box (AJB)
53 to Splice 14401-S15
53 to 14A583 Cargo space lamp
53 to 14335 Interior map lamps asy, rear

14A488 - S34

Splice Location: **F5** - Near RH Passenger Seat T/O

1003 to 14C719 Climate contr st mod, drv side
1003 to Central Junction Box (CJB)
1003 to 14C719 Climate contr st mod, pass side

14A488 - S35

Splice Location: **F4** - Near Restraints Control Module (RCM) T/O (C310b)

1566 to 14C719 Climate contr st mod, pass side
1566 to 14398 Battery Junction Box (BJB)
1566 to 14C719 Climate contr st mod, drv side

14A488 - S40

Splice Location: **B1** - LH Side Cowl Near Grommet

400 to 15C670 Roof opening panel motor asy
400 to Power window motor, left front
1002 to Splice 14401-S13
1002 to Navigation Eletr Contr Unit (ECU) mod
1678 to Antenna gain module

14A488 - S60

Splice Location: **A3** - Near VAPS Module T/O (C2231a)

914 to Splice 14401-S22
914 to Low tire pressure module
914 to Navigation Eletr Contr Unit (ECU) mod
914 to Telematics Control Unit (TCU) module
914 to Variable Assist Pwr Stng (VAPS) mod

14A488 - S61

Splice Location: **A3** - Near VAPS Module T/O (C2231a)

915 to Splice 14401-S23
915 to Low tire pressure module
915 to Navigation Eletr Contr Unit (ECU) mod
915 to Telematics Control Unit (TCU) module
915 to Variable Assist Pwr Stng (VAPS) mod

14A488 - S63

Splice Location: **F7** - Near Side Impact Sensor, passenger 2 T/O (C3212)

460 to Splice 14398-S15
460 to Low tire pressure module
460 to Central Security Module (CSM)

14A488 - S69

Splice Location: **A2** - Near Variable Assist Power Steering (VAPS) Module T/O (C2231a)

679 to 394 to Splice 14401-S18
679 to Navigation Eletr Contr Unit (ECU) mod
679 to Variable Assist Pwr Stng (VAPS) mod

14A488 - S70

Splice Location: **G10** - Rear, RH Side D-Pillar

1001 to Navigation amplifier
1001 to Navigation amplifier
1001 to 14401 Central Junction Box (CJB)

14A488 - S73

Splice Location: **B5** - Between A-Pillar and B-Pillar, RH Side

1002 to 14334 Inside rear view mirror unit
1002 to 14401 Central Junction Box (CJB)
1002 to Low tire pressure module
1002 to Telematics Control Unit (TCU) module