
1
2
3
4
5
6
7
8
A
B
C
D
E
F
C2247
In–vehicle temperature/humidity sensor
C280
Traction control switch
C253
Message center switch
C2007
Passive anti–theft transceiver
C218a
C218b
Air bag sliding contact (14A664)
C250
Ignition switch (11572)
C202a
C202b
C202c
Multifunction switch
14401
C219
C284
Four–wheel drive switch
C226
Steering position sensor (18B015)
C278
Brake pedal position switch (13480)
front of vehicle
dash panel