

Engine compartment, LH side, front

B29	Ice warning sensor	C 1	E1	Headlamp, left	C 4
C648		D 2	E3	Turn lamp, left front	C 4
C753		B 4	E40	Side lamp, left front	B 4
C835		C 4	G22		B 1
C974		C 1	R5	Daytime running lamps resistor	E 2
C1916		C 4			