Master window/door lock/unlock switch

Window switch – Schematic



Master window/door lock/unlock switch

- 0) Neutral
- 14) Driver
- 15) Passenger
- 16) Left rear
- 17) Right rear
- 18) Up
- 19) Down
- 20) One–touch down
- 21) Left flip window open
- 22) Left flip window close
- 23) Right flip window open
- 24) Right flip window close

Terminals

C508a



F08165

C508b



F06213