G2 -4


M75
Mirror motor, driver side
3
C807
N137
Door lock/unlock switch, driver
N70
Power mirror adjust switch
2
4
C1927
C740
31-LH28
.5 BK
31-AD12
.5 BK
31-HB37
.5 BK
31-AA34
.5 BK
N309
Window operating switch, driver side front
N310
Window operating switch, driver side for passenger side
K50
One–touch window relay
M67
Door lock motor, driver side
3
C74
3
C2125
1
C738
6
C707
31-AJ7
1.5 BK
31-AJ9
2.5 BK
31-AJ16
.5 BK
31-AA58
.5 BK
S257
31-DA11
2.5 BK
2
C148
31-DA11
2.5 BK
G2