

Battery Junction Box (BJB) (14A003)

R1.47	Horn relay	A1
R1.48	Fuel pump relay	B1
R1.49	High beam relay	C1
R1.50	Fog lamp relay	D4
R1.51	Daytime Running Lamps (DRL) relay	C4
R1.52	A/C clutch relay	B4
R1.53	Trailer tow relay, right turn	C1
R1.54	Trailer tow relay, left turn	D1
R1.55	Blower motor relay	E4
R1.56	Starter motor relay	E1
R1.57	Powertrain Control Module (PCM) relay	D1
R1.58	Ignition relay	E4
R1.59	Brake applied relay	F1
D1.60	Powertrain Control Module (PCM) diode	G2
D1.61	A/C indicator clutch diode	G1
CB1.62	Power windows circuit breaker	E2
C1117	Joint connector 1	F4
C1118	Joint connector 2	G4