C180 (BK)

9H589

Camshaft position sensor (6B288)

F02109

Pin	Circuit	Circuit function
1	1202 (BN/LG)	Ground
2	282 (DB/OG)	Camshaft position sensor (6B288), input

C181 (BK)

9H589

Fuel injector 1 (9F593)



F02058

Pin	Circuit	Circuit function
1	555 (TN)	Fuel injector 1, control
2	361 (RD)	Voltage supplied in Start and Run (overload protected)

C182 (BK)

9H589

Fuel injector 2 (9F593)



F02058

Pin	Circuit	Circuit function
1	556 (WH)	Fuel injector 2, control
2	361 (RD)	Voltage supplied in Start and Run (overload protected)

C183 (BK)

9H589

Fuel injector 3 (9F593)



F02058

Pin	Circuit	Circuit function
1	557 (BN/YE)	Fuel injector 3, control
2	361 (RD)	Voltage supplied in Start and Run (overload protected)

C184 (BK)

9H589

Fuel injector 4 (9F593)



F02058

Pin	Circuit	Circuit function
1	558 (BN/LB)	Fuel injector 4, control
2	361 (RD)	Voltage supplied in Start and Run (overload protected)

C185 (BK)

9H589

Fuel injector 5 (9F593)



F02058

Pin	Circuit	Circuit function
1	559 (TN/BK)	Fuel injector 5, control
2	361 (RD)	Voltage supplied in Start and Run (overload protected)