Ignition switch (11572) (continued)

Component testing procedure

Circuit to test	Connect self–powered test light or ohm-meter to terminals	Move switch to these positions	A good switch will indicate
Headlamp circuit	7, C205b and 6, C205b	Off	Open circuit
		Park	Open circuit
		Head	Closed circuit
Park lamps	13, C205a and 14, C205a	Off	Open circuit
		Park	Closed circuit
		Head	Closed circuit
Interior lamp	12, C205a and 7, C205b	Knob rotated fully counterclockwise (in detent)	Closed circuit
		Knob rotated fully clockwise (out of detent)	Open circuit