-82

C808

F05027

14A584

M76
Mirror motor, passenger side



Pin	Circuit	Circuit Function
1	32-AD9 (WH/GN)	Switched between: Battery voltage, Ground or Open
2	34-AD10 (BU/YE)	Switched between: Battery voltage, Ground or Open
3	33-AD11 (YE/VT)	Switched between: Battery voltage, Ground or Open
4	15S-HB36 (GN/OG)	Voltage, ignition switch in Start or Run (not overload protected), switched
5	31-HB36 (BK)	Ground