Battery Junction Box (BJB) (14A003)

Fuse	Amps	Circuits protected
F1.1	5	Hydro max module
F1.2	10	A/C clutch relay
F1.3	20	4R100 transmission, Oxygen sensor (O2S), EVAP canister purge valve
F1.4	5	Powertrain Control Module (PCM) (12A650)
F1.5	15	Fuel pump relay, Powertrain Control Module (PCM) (12A650), A/C clutch relay, Mass Air Flow (MAF) sensor (12B579), Fuel injectors, Idle air control valve (IAC) (9F715)
F1.6	20	Main light switch (11654)
F1.7	15	Digital Transmission Range (DTR) sensor (7F293)
F1.8	10	Brake pressure switch (2B264), Brake pedal position switch (13480)
F1.9	5	Instrument cluster
F1.10	20	Daytime running lamps resistor
F1.11	30	Ignition coil, Ignition transformer capacitor, PCM power relay
F1.12	20	Trailer exterior lamp relay, Trailer tow relay, reversing lamp
F1.13	30	Trailer electronic brake control module
F1.14	60	Central Junction Box (CJB) (14A068)
F1.15	–	not used
F1.16	60	ABS control module (2C219)
F1.17	–	not used
F1.18	20	Horn relay
F1.19	–	not used
F1.20	40	PCM power relay
F1.21	20	Fuel pump relay
F1.22	20	Cigar lighter, Data Link Connector (DLC) (14489)
F1.23	40	Blower motor relay
F1.24	40	Central Junction Box (CJB) (14A068)
F1.25	50	Ignition switch (11572)
F1.26	60	Ignition switch (11572)
F1.27	30	Multifunction switch (13K359), Main light switch (11654)
F1.28	–	not used
F1.29	60	Hydro max relay