F30

-17


P91
Central Junction Box (CJB)
15
F30
7.5A
2 C362
2 C362
1 C365
8 C366
15-GG14
.75 GN/RD
15-GE42 .5 GN/YE
1 C2114
15-CF45 1 GN/BK
15-GE42 .35 GN/YE
15 C808b
C467
6 C717
A30
Instrument cluster
A162
Display assembly, auxiliary warning system
N83
Traction Control System (TCS) disable switch
15-AA17 .75 GN/WH
15 C58
15-TA21 .5 GN/BK
15-AA17 .5 GN/WH
8 C931
15-GG15 .35 GN/BK
10 C451a
11 C440
A77
Anti–theft/central locking module
N93
Gearshift lever unit
A35
Instrument interface module