C390

14401

A102
Passive anti–theft transceiver module



F04116

Pin	Circuit	Circuit Function
1	15-GL37A (GN/BK)	Voltage, ignition switch in Start or Run (not overload protected)
	15-GL37 (GN/BK)	Voltage, ignition switch in Start or Run (not overload protected)
2	91-GL1 (BK/YE)	Ground
3	10-GL37 (GY/OG)	Signal 2 (Y–direction, reverse, downward)
4	8-GL37 (WH/GN)	Sensor signal