-21


700–03–00–19
conventional cluster
700–03–00–20
electronic cluster
DA25 .5 BU
22 C1000
P93
Battery Junction
Box (BJB)
P55
Battery Junction
Box (BJB) joint con-
nector
21 14 13 12 18 17 16 C1000
FA04 .5 BU
HA40 .5 BU FA02 .5 BU FA07 .5 BU
HA42 .5 GY
AV76 .5 BK/RD
DA30 .5 BU
P93
Battery Junction
Box (BJB)
1 C180
K314
High speed fan
control relay 2
1 C181
K313
High speed fan con-
trol relay 1
1 C179
K309
Low speed fan con-
trol relay
P51
Engine compart-
ment relay box
3 2 C176
K59
A/C relay
1 C182
K4
Fuel pump relay
1 C183
K302
Bulb check relay