
1
2
3
4
5
6
7
8
A
B
C
D
E
F
14401
Wiring harness –
Main
C2097
Passive anti–theft
transceiver
C218a
Air bag sliding
contact (14A664)
C218b
Air bag sliding
contact (14A664)
Auxiliary relay box 1
14401
Wiring harness –
Main
front of vehicle
bottom of steering column