| Item | Part Number | Description |
|---|---|---|
| 1 | 13407 | Wiring harness – Rear lamp jumper |
| 2 | 13412 | Wiring harness – License plate lamps |
| 3 | 14290 | Wiring harness – Dash panel to headlamp junction |
| 4 | 14300 | Wiring harness – Battery (+) |
| 5 | 14301 | Wiring harness – Battery (–) |
| 6 | 14334 | Wiring harness – Interior lamps |
| 7 | 14335 | Wiring harness for interior illumination |
| 8 | 14401 | Wiring harness – Main |
| 9 | 9H307 | Wiring harness – Fuel pump/fuel gauge sender – Fuel tank unit |
| 10 | 14630 | Wiring harness – passenger door |
| 11 | 14631 | Wiring harness – driver door |
| 12 | 14632 | Wiring harness – Right door, Rear |
| 13 | 14633 | Wiring harness – Left door, Rear |
| 14 | 10K337 | Wiring harness – Alternator to battery |
| 15 | 12B637 | Wiring harness – Engine controls sub assembly |
| 16 | 13B783 | Wiring harness – Rear interior lamp, manual transmission |
| 17 | 13N052 | Wiring harness – Headlamp jumper |
| 18 | 14A005 | Wiring harness – Body |
| 19 | 14A012 | Wiring harness – ash receptacle lamp feed |
| 20 | 14A411 | Wiring harness – PRNDL jumper |
| 21 | 14A594 | Wiring harness – Non–Speed control jumper |
| 22 | 14A699 | Wiring harness – Front seats, driver side |
| 23 | 14A698 | Wiring harness – Front seats, Passenger side |
| 24 | 14B720 | Wiring harness – seat back control extension |
| 25 | 14B060 | Wiring harness – Starter motor relay and battery ground |
| 26 | 17A413 | Wiring harness – Rear wiper motor assembly |

| Item | Part Number | Description |
|---|---|---|
| 27 | 18C620 | Wiring harness – Wiring harness – Rear window heater ground |
| 28 | 18C629 | Wiring harness – Heater blower switch jumper |
| 29 | 19A397 | Wiring harness – Cellular phone antenna |
| 30 | 19A442 | Wiring harness – Cellular phone |
| 31 | 19A456 | Wiring harness – Cellular phone |
| 32 | 19B113 | Wiring harness – Radio amplifier |
| 33 | 19D570 | Wiring harness – Electronic Automatic Temperature Control (EATC) sub assembly |
| 34 | 19D887 | Wiring harness – manual A/C, jumper |
| 35 | 9D866 | Wiring harness – Evaporative emission (EVAP) canister vent valve (9F945) |
| 36 | 14N000 | Wiring harness – Single jumper |
| 37 | 14402 | Wiring harness – Warning horn |
| 38 | – | Battery Junction Box (BJB) (14A003) |
| 39 | – | Central Junction Box (CJB) (14A068) |
| 40 | – | Relay center box 1 |
| 41 | – | Relay center box 2 |
| 42 | – | ABS control module (2C219) |
| 43 | 7000 | AX4S/4F50N Transmission |
| 44 | 12A650 | Powertrain Control Module (PCM) (12A650) |
| 45 | – | Generic Electronic Module (GEM) (14B205) |
| 46 | – | Restraints control module (14B321) |
| 47 | 18C612 | Remote Climate Control (RCC) module |
| 48 | – | Battery (10655) |
| 49 | 9C734 | Speed control servo (9C735) |