
1
2
3
4
5
6
7
8
A
B
C
D
E
F
C515
Perimeter anti–theft reset switch
C505
Door lock switch, driver side (14028)
C522
Exterior rear view mirror, left
C504
Master window adjust switch (14529)
C526
Door ajar switch, driver side front (14018)
C525
Door lock unit, driver side front (5421813)
C510
C207
Luggage compartment lid release switch
C523
Speaker, left front (18808)
front of vehicle
left front door