Battery Junction Box (BJB) (14A003)

Maxi–fuse	Amps	Circuits protected
F1.1	30	Subwoofer amplifier (18C804), Central Junction Box (CJB) (14A068), Navigation system amplifier
F1.2	20	Power point (19N236)
F1.3	20	not used
F1.4	15	Horn relay
F1.5	20	Fuel pump relay
F1.6	20	Power point, left rear
F1.7	30	Heated seat module, driver side front, Heated seat module, passenger side front
F1.8	–	not used
F1.9	–	not used
F1.10	10	Air suspension module (3C142)
F1.11	30	Heated seat module, left rear, Heated seat module, right rear
F1.12	20	Power point, right rear
F1.13	15	Generator
F1.14	20	Cigar lighter, left rear door, Cigar lighter, right rear door
F1.15	–	not used
F1.16	–	not used
F1.17	–	not used
F1.18	–	not used
F1.19	15	Powertrain Control Module (PCM) (12A650), Mass Air Flow (MAF) sensor (12B579), Fuel injectors, Idle Air Control (IAC) valve (9F715), Differential Pressure Feedback EGR (DPFE) sensor (9J460)
F1.20	15	EVAP canister vent control solenoid, EVAP canister purge valve, 4R70W transmission, Heated oxygen sensors (HO2S)
F1.21	–	not used
F1.22	–	not used
F1.23	–	not used
F1.24	–	not used

Maxi–fuse	Amps	Circuits protected
F1.101	50	Starter relay (11450), Ignition switch (11572)
F1.102	50	Engine cooling fan motor
F1.103	30	Blower motor relay
F1.104	40	Rear window defrost relay
F1.105	30	PCM power relay
F1.106	40	ABS control module (2C219)
F1.107	40	Accessory delay relay, Central Junction Box (CJB) (14A068)
F1.108	30	Adjustable pedal switch, Lumbar adjust switch, right front, Seat adjust switch, passenger side front, Central Junction Box (CJB) (14A068), Lumbar adjust switch, left front (14B691), Driver seat module (14C718), Power seat switch, left
F1.109	40	Trunk pull–down module, Power luggage compartment lid module
F1.110	–	not used
F1.111	–	not used
F1.112	40	Ignition switch (11572)
F1.113	40	Central Junction Box (CJB) (14A068)
F1.114	30	Air suspension compressor relay
F1.115	40	Central Junction Box (CJB) (14A068)
F1.116	30	Windshield wiper motor (17508)
F1.117	30	Seat adjust switch, passenger side front, Lumbar adjust switch, right front
F1.118	20	ABS control module (2C219)
F1.601	–	not used
F1.602	–	not used