
FROM C248
PAGE 100-1
C
400 LB/BK
C509
INSTRUMENT ILLUMINATION
PAGE 71-2
19 LB/RD
C510
LEFT FRONT POWER WINDOW SWITCH
151–14 C1
LEFT FRONT POWER WINDOW SWITCH
PAGE 100-3
SWITCH ILLUMINATION
OTD SWITCH
LEFT WINDOW SWITCH
RIGHT WINDOW SWITCH
UP
DOWN
LEFT FRONT POWER WINDOW SWITCH
PAGE 100-3
0V C510
57 BK
57 BK
995 GY
991 TN/LB
992 WH/BK
313 WH/YE
314 TN/LB
C509
FROM S257
PAGE 100-3
G
INSTRUMENT ILLUMINATION
PAGE 71-2
19 LB/RD
193 YE/LG
C609
RIGHT FRONT POWER WINDOW SWITCH
151–14 A5
E
D
F
FROM C248
PAGE 100-1
TO C248
PAGE 100-1
TO C506
PAGE 100-1
S251
0V C609
57 BK
333 YE/RD
334 RD/YE
C606
RIGHT FRONT POWER WINDOW MOTOR
151–14 F3
M
57 BK
SEE GROUNDS
PAGE 10-7
S600
57 BK
SEE GROUNDS
PAGE 10-8
G200