C802
Speaker, right rear (18808)

C801
Window adjust switch, right rear (14A412)

C803
Power window motor, right rear (23394)

C804
Door lock actuator, right rear (218A42)

C820
Door ajar switch, passenger side rear (14018)

C702
Speaker, left rear (18808)

C701
Window adjust switch, left rear (14A412)

C703
Power window motor, left rear (23394)

C704
Door lock actuator, left rear (218A43)

C715
Door ajar switch, driver side rear (14018)



C700
C800

14A488

14683

front of vehicle

rear door