46-1 AIR BAG RESTRAINT SYSTEM

For diagnostic information, refer to Section 501-20B of the Workshop Manual.

Warning
Do not attempt to diagnose or troubleshoot air bag circuitry without consulting the Workshop Manual. Improper troubleshooting could cause the air bags to deploy inadvertently, causing injury.

EXCURSION



*** SHORTING BARS CONNECT HARNESS TERMINALS WHEN THE HARNESS IS DISCONNECTED.**