
Hot in run or acc
F2.12 10A
Hot in run
F2.14 10A
Hot in start or run
F2.17 5A
P91 Central Junction Box (CJB) (14A068)
A7 ABS control module (2C219)
D20 Data Link Connector (DLC) (14489)
B119 Side air bag sensor, left (14B345)
A226 Passenger safety belt retractor pretensioner
A30 Instrument cluster
Indicator will flash a lamp fault code if module detects a system hard fault. The lamp will then stay on until fault is corrected.
B118 Side air bag sensor, right (14B345)
A225 Driver safety belt retractor pretensioner
A208 Restraints control module (14B321)
N475 Passenger Air bag Deactivation (PAD) switch
P140 Air bag sliding contact (14A664)
A43 Passenger air bag module (15044A74)
A155 Side air bag module, left
A154 Side air bag module, right
Electronically connects air bag and steering wheel controls to body harness.
Inflates upon impact, according to sensor reaction
A42 Driver air bag unit (78043B13)