29-1 TRANSMISSION CONTROLS (ALLISON ELECTRONIC)

For diagnostic information, refer to Section 307-01 of the Workshop Manual.

* NON-SUPERCREWZER
** SUPERCREWZER