Master window adjust switch (14529)

Schematic



N447
Master window adjust switch (14529)
0) Rest
1) Driver
2) Passenger
3) Left rear
4) Right rear
5) Up
6) Down
8) Lock

Terminals

C504b



C504a