EXCEPT EXECUTIVE



C417

SUBWOOFER AMPLIFIER

PIN	CIRCUIT	CIRCUIT FUNCTION
1	173 (DG/VT)	Subwoofer High Audio Mute
2	–	NOT USED
3	694 (BK/LG)	Ground
4	–	NOT USED
5	720 (RD/YE)	Power (Hot at All Times)
6	–	NOT USED
7	167 (BN/OG)	Subwoofer High Audio (+)
8	168 (RD/BK)	Subwoofer High Audio (–)
9	–	NOT USED
10	–	NOT USED

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C123	31-3
C2009	44-4