C258

14A005

N448
Auto clutch mode
select switch



F04177

Pin	Circuit	Circuit function
1	8-TC18 (WH)	Sensor signal
2	–	not used
3	9S-TC18 (BN)	Sensor signal return (reference/ground), Switched
4	–	not used
5	–	not used

C260

14401



F16029

19D887



F16030