100-1 POWER WINDOWS

2002 EXPEDITION/NAVIGATOR

For diagnostic information, refer to Section 501-11 of the Workshop Manual.