Ignition switch (11572)

Component testing procedure

Circuit to test	Connect self–powered test light or ohmmeter to terminals	Move switch to these positions	A good switch will indicate
Starter relay circuit	B4 and ST	Accessory	Open circuit
		Lock	Open circuit
		Off	Open circuit
		Run	Open circuit
		Start	Closed circuit
Run/Acc power circuit	B5 and I1	Accessory	Open circuit
		Lock	Open circuit
		Off	Open circuit
		Run	Closed circuit
		Start	Closed circuit
Acc power circuit	B5 and A1	Accessory	Closed circuit
		Lock	Open circuit
		Off	Open circuit
		Run	Open circuit
		Start	Open circuit
Run power circuit	B1 and A1	Accessory	Open circuit
		Lock	Open circuit
		Off	Open circuit
		Run	Closed circuit
		Start	Open circuit
	B3 and A3	Accessory	Open circuit
		Lock	Open circuit
		Off	Open circuit
		Run	Closed circuit
		Start	Open circuit
	B4 and A4	Accessory	Open circuit
		Lock	Open circuit
		Off	Open circuit
		Run	Closed circuit
		Start	Open circuit