37-1 SHIFT LOCK

2001 F-150

For diagnostic information, refer to Section 307-05 of the Workshop Manual.

*** BRAKE PEDAL POSITION (BPP) SWITCH CLOSED**



Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.