

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C228	13-15
C256	86-2
C352	59-5

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.