

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C232	13-15
C270	13-16
C290	66-3
C405	111-3

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.