
Cell 20 – Starting System
Cell 21 – Engine Ignition
Cell 23 – Engine Controls – ZETEC–VCT
Cell 24 – Engine Controls – Duratec–VE
Cell 30 – Transmission Controls
Cell 31 – Vehicle Speed Control
Cell 59 – Multifunction Electronic Control Modules
Cell 130 – Radio
Cell 44 – Horn/Cigar Lighter
Cell 60 – Instrument Cluster
Cell 71 – Illumination
Cell 54 – Air Conditioning
Cell 53 – Heater
Cell 89 – Courtesy Lamps
Cell 124 – Power Mirrors
Cell 101 – Roof Opening Panel
Cell 56 – Rear Window Defrost
Cell 113 – Luggage Compartment Lid Release
Cell 92 – Exterior Lamps
Cell 14 – Module Communications Network
Cell 81 – Wipers and Washers
Cell 85 – Headlamps
Cell 90 – Turn/Stop/Hazard Lamps
Cell 92 – Exterior Lamps
Cell 86 – Fog Lamps
Cell 97 – Daytime Running Lamps
Cell 90 – Turn/Stop/Hazard Lamps
Cell 93 – Reversing Lamps
Cell 120 – Power Seats
Cell 46 – Air Bags
Cell 33 – Cooling Fan
Cell 42 – ABS
Cell 12 – Charging System
Cell 112 – Anti–Theft
Cell 117 – Remote Control Alarm and Locks
Cell 100 – Power windows
Cell 110 – Power Door Locks