93-1 REVERSING LAMPS

2001 WINDSTAR

For diagnostic information, refer to Section 417-01 of the Workshop Manual.



CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C103	23-9
C340	59-12
C341	59-12
C445	131-3

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.