
1
2
3
4
5
6
7
8
A
B
C
D
E
F
15525
C1168
C1148
C141
Heated Oxygen Sensor (HO2S) #22 (9G444)
C172
Heated Oxygen Sensor (HO2S) #21 (9F472)
C107
Cylinder–head temperature sensor (6G004)
C1107
Output Shaft Speed (OSS) sensor (7M101)
C142
Heated Oxygen Sensor (HO2S) #12 (9G444)
C169
C1131
Reversing lamps switch
front of vehicle
Manual