C1958 (GY)

14014



F04148

14K024



F04146

C1960 (YE)

14014

B119
Side air bag sensor, left (14B345)



F02058

Pin	Circuit	Circuit function
1	9-JA41 (BN)	Sensor signal return (reference/ground)
2	8-JA41 (WH)	Sensor signal

C1961 (YE)

14014

B118
Side air bag sensor, right (14B345)



F02058

Pin	Circuit	Circuit function
1	9-JA43 (BN/WH)	Sensor signal return (reference/ground)
2	8-JA43 (WH/VT)	Sensor signal