

1
2
3
4
5
6
7
8
A
B
C
D
E
F
C604
Window adjust switch, passenger side
C627
Seat adjust switch, passenger side front
C602a
Door ajar switch, passenger side front (14018)
C605
Door lock switch, passenger side (14028)
C611
C615a
Exterior rear view mirror, right
C602b
Door ajar switch, passenger side front (14018)
C615b
Exterior rear view mirror, right
14A005
C609
Door lock unit, passenger side front (5421812)
C612
Speaker, right front (18808)
C610
C608
Power window motor, passenger side front (23394)
front of vehicle
right front door