

C292 (GRAY)

IGNITION SWITCH

PIN	CIRCUIT	CIRCUIT FUNCTION
B1	1050 (LG/VT)	Battery Input
A1	297 (BK/LG)	Output (Hot in Run or Acc)
B2	37 (YE)	Battery Input
A2	489 (PK/BK)	Output (Hot in Run)
B3	37 (YE)	Battery Input
A3	489 (PK/BK)	Output (Hot in Run)
B4	37 (YE)	Battery Input
STA	32 (RD/LB)	Output (Hot in Start)
A4	687 (GY/YE)	Output (Hot in Run)
B5	1050 (LG/VT)	Battery Input
I-1	1044 (WH/YE)	Output (Hot in Start or Run)
GND	57 (BK)	Ground
P1	–	NOT USED
P2	409 (TN/BK)	Ground in Start Output
I-2	–	NOT USED



RELAY BOX