DAYTIME RUNNING LAMPS (DRL) 97-2



CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C236	62-6
C246	13-19
C259	81-3

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.