C2117 (GN)

14K155



F02098

19K315



F02096

C2121

14K024

N155
Liftgate/decklid release switch



F07016

Pin	Circuit	Circuit function
1	–	not used
2	31S-AA30 (BK/YE)	Ground, Switched
3	–	not used
4	31-LH44 (BK) + 31-LD23 (BK)	Ground
	31-LH44 (BK) + 31-AA30 (BK)	Ground
5	64S-LH44 (BU) + 64S-LK29 (BU/RD)	Variable D.C. voltage (not overload protected), Switched
6	–	not used
7	31-AA30 (BK) + 31-LH44 (BK)	Ground
	31-AA30 (BK) + 31-TA32 (BK)	Ground