
FROM BATTERY JUNCTION BOX
PAGE 13-1
A
7
25A
6
30A
C
TO BATTERY JUNCTION BOX
PAGE 13-3
BATTERY JUNCTION BOX
151–1 A10
406 BN/WH
406 BN/WH
65 DG
65 DG
S126
S127
65 DG
65 DG
65 DG
65 DG
406 BN/WH
406 BN/WH
406 BN/WH
151–7 A5
C180F
C180M
406 BN/WH
151–9 B10
C902M
C902F
406 BN/WH
C112M
C112F
65 DG
C118
C904
C119
C113
1
2
5
1
5
1
1
4
LIFTGATE WASHER PUMP MOTOR
PAGE 82-1
LIFTGATE WIPER MOTOR
PAGE 82-1
LIFTGATE WIPER RELAY
PAGE 82-1
WINDSHIELD WIPER ON/ OFF RELAY
PAGE 81-2
WINDSHIELD WIPER SPEED RELAY
PAGE 81-2
BATTERY JUNCTION BOX
151–1 A10
WINDSHIELD WASHER PUMP MOTOR
PAGE 81-2
WINDSHIELD WIPER MOTOR
PAGE 81-2