

C264
AIR BAG DIAGNOSTIC MONITOR

PIN	CIRCUIT	CIRCUIT FUNCTION	PIN	CIRCUIT	CIRCUIT FUNCTION
1	941 (LG)	Steering Column Air Bag Feed Monitor	15	942 (BU)	Steering Column Air Bag Return
2	950 (GN)	Run Only Ignition	16	–	NOT USED
3	–	NOT USED	17	9 (WH)	Power (Hot at All Times)
4	–	NOT USED	18	–	NOT USED
5	–	NOT USED	19	529 (OG/LB)	Data Link Connector Signal Feed
6	–	NOT USED	20	–	NOT USED
7	952 (PK/GN)	Air Bag Indicator Control (Hot in Start or Run)	21	57 (BK)	Ground
8	–	NOT USED	22	57 (BK)	Ground
9	–	NOT USED	23	–	NOT USED
10	–	NOT USED	24	–	NOT USED
11	950 (GN)	Run Only Ignition	25	–	NOT USED
12	950 (GN)	Run Only Ignition	26	–	NOT USED
13	940 (GY)	Warning Chime Signal Feed	27	–	NOT USED
14	943 (YE/RD)	Passenger Air Bag Return	28	944 (RD)	Passenger Air Bag Feed