F1.19, F2.11 -6


30
F1.19
40A
P93
Battery Junction
Box (BJB)
30) Hot at all
times
37 12 YE
S130
37 12 YE
37 12 YE
10 C270b
30 C1017
K22
Starter relay
P93
Battery Junction
Box (BJB)
P91
Central Junction
Box (CJB)
30) Hot at all
times
30 C2076
K41
Ignition relay
30
F2.11
10A
85 C2075
K126
Accessory delay
relay
1 C270d
32 20 RD/LB
4 C250
N278
Ignition switch