
* START OR RUN
TO S138
PAGE 26-6
G
796 LB
151–1 C1
C120M
C120F
796 LB
C100
REVISED
CAMSHAFT POSITION (CMP) SENSOR
151–6 F8
C100
795 DG
151–6 A2
C120F
C120M
795 DG
FROM S155
PAGE 26-4
Q
391 RD/YE
HOT AT ALL TIMES
BATTERY JUNCTION BOX
13
15A
PAGE 13-3
883 PK/LB
*12V
12V
2
3
1
5
WOT RELAY
PAGE 54-3
BATTERY JUNCTION BOX
151–6 C10
321 GY/WH
331 PK/YE
AIR CONDITIONER/ HEATER
PAGE 54-3
C174
85
69
SOLID STATE
POWERTRAIN CONTROL MODULE (PCM)
151–6 B1