

RH engine compartment

12A522	F 3	
14A103	A 3	
B14	Wheel speed sensor, right front	B 5
C103		B 3
C105		B 2
C107		E 1
C109		B 2
C111		B 1
C121		B 5
C123		B 2
C127		B 4
C129		E 4
C131		D 1
C153		E 2
C154		E 2
C192		E 1
E7	Headlamp, right	B 2
E8	Turn lamp, right front	D 1
E32	Side lamp, right front	B 2
E166	Park/turn lamp, right front	B 3
G103		B 4
M112	Windshield washer pump motor	B 2
M217	Rear window washer pump motor	E 1
M219	Speed control actuator	B 4
N75	A/C compressor cycling switch	E 4
N76	Dual pressure switch	E 2
N400	Washer fluid level switch	B 1
V7	A/C Compressor clutch diode	E 2
Y31	A/C clutch solenoid	E 2