Item	Part Number	Description
1	–	Battery Junction Box (BJB) (14A003)
2	–	ABS control module (2C219)
3	–	Injector Driver Module (IDM)
4	12A581	Wiring harness – Engine control sensor
5	–	Powertrain Control Module (PCM) (12A650)
6	14290	Wiring harness – Dash panel to headlamp junction
	13A006	Wiring harness – Headlamps (Stripped chassis)
7	14406	Wiring harness – Fuel tank sender
8	14401	Main wiring harness
9	–	Wiper Control Module (WCM)
10	–	Electronic Crash Sensor (ECS) module
11	–	Central Junction Box (CJB) (14A068)
12	–	Rear Seat Entertainment (RSE) module
13	–	Remote keyless entry module (15K602)
14	14A200	Wiring harness – Window regulator relay switch
15	14405	Wiring harness – Tail lamps
	13A409	Wiring harness – Rear lamp connector (E550)
16	14335	Wiring harness – Interior illumination
17	14334	Wiring harness – Interior lamps
	13A710	Wiring harness – Rear interior lamp (without rear control)
18	14A699	Wiring harness – Power seats (with power driver seat)
	14C719	Wiring harness – Seat control feed jumper
19	14631	Wiring harness – Window regulator, left front door
	19A041	Wiring harness – Radio speaker (E550)
20	–	Auxiliary Powertrain Control Module (APCM)
21	14014	Wiring harness – Door lock feed
22	14630	Wiring harness – Window regulator, right front door
23	12B637	Wiring harness – Engine control sensor and fuel charge
	9D930	Wiring harness – Fuel charge (4.2L, 7.5L Diesel)

Item	Part Number	Description
24	7C078	Wiring harness – Transmission control selector neutral switch
25	10K699	Wiring harness – Auxiliary battery feed
26	12A690	Wiring harness – Engine Control
27	13412	Wiring harness – Rear license plate lamp
28	13A576	Wiring harness – Trailer lamp feed
29	14026	Wiring harness – Right rear door lock
30	14300	Wiring harness – Battery output
31	14301	Wiring harness – Junction block to engine ground
32	10K304	Wiring harness – Alternator to starter motor solenoid (Diesel with dual generators)
	11A004	Wiring harness – Starter motor relay to solenoid
33	14305	Wiring harness – Alternator rectifier system
34	14439	Wiring harness – Starter relay to fuse junction panel
35	14A346	Wiring harness – Trailer battery feed
36	14A348	Wiring assembly – trailer brake control switch
37	14A655	Wiring harness – Fuel tank sender extension
38	14B102	Wiring harness – Temperature sensor jumper
39	14N144	Wiring harness – Battery positive
40	19949	Wiring harness – A/C blower motor
41	19A178	Wiring harness – Radio speaker extension, left
42	2B392	Wiring harness – Brake control speed sensor
43	9A350	Wiring harness – Fuel pump
44	9K499	Wiring harness – Exhaust emission control
45	–	Daytime Running Lamps (DRL) module
46	13A718	Wiring harness – Interior lamp feed jumper (Stripped chassis)
47	14370	Wiring harness – Connector (Stripped chassis)
48	15A404	Wiring harness – Marker lamp to switch (E550)
49	17B587	Wiring assembly – windshield wiper switch to windshield wiper motor (Stripped chassis)
50	2B516	Wiring harness – Brake skid control actuator (E550)